



CAMPING EQUIPMENTCO.COM

www.campingequipmentco.com

Tent Assembly Instructions

ATLAS

Congratulations and thanks for your purchase! This booklet will tell you everything you need to properly assemble your tent and maintain it.

Follow these instructions carefully and you'll enjoy many years of use – please note that this product is intended for mild, 3 season, family camping use and not for extreme conditions of weather and use

Practice setting-up and taking-down the tent a few times at home before use at the camping site.

1

Carrying bag X 1

Fly X 1

Repair kit X 1

Long PP Webbing X 4

Plastic anchor X 8

1.91 meters steel X 2 lines, 4 sections per line

2.47 meters steel X 4 lines, 5 sections per line

7.93 meters X 4 lines, 1 sections per line (already put in tent)

2

A) Remove the PP webbing and drop the folded tent to the ground gently.

B) The tent will stand on its own after pulling the 4 corner poles up.

3

The roof can be held up by installing the 2 short fiberglass poles (1.91 m. each) at the interior ceiling.

Insert the remaining 4 long fiberglass poles through the fabric sleeves just above each entrance.

4


Tie the pp webbings.

Stake down the corners and the pp webbings.

The tent is now set up and ready to be used

Visit us online at www.campingequipmentco.com and be sure to join our Facebook and Twitter pages for new product information and to receive special offers and discounts on our camping equipment.


5



2 persons pods/sleeping quarters, Miga (sold separately) can be attached to the Atlas (main screen house) with the concealed zippers.

Up to 2 pods/sleeping quarters can be joined to Atlas.

6




A) Remove all 6 fiberglass poles as mentioned in Fig. 3.

B) Drop the stretched tent gently on its side so the tent is lying flat on the ground. Press down the 2 corner poles diagonally as showed in Fig. 6B.

C) Now there are 2 panels lying on the ground. Fold the 2 panels towards each other as showed in sketch 6C.


7



A) Grab the 2 sides of the tent and pull them towards each other as showed in 7A

B) You now have 2 loops or a distorted "8" shape figure as showed in B.

8



A) Bend and tug with one hand, the top loop towards the centre of the folded tent and press down the top loop with the other hand as showed 8A.

B) Try to fold the tent in 3 layers/loops to form a smallest circle. Lay the folded circle on top of the cross PP webbing. Secure the webbing with Velcro.

Store the folded tent in the carry bag.

CARING FOR YOUR TENT:

- Keep it clean: Don't set up your tent in the mud, avoid putting muddy clothing and gear in the sleeping compartments as sand and dirt can scratch the water proof coating and damage zippers
- UV light can accelerate fabric degradation. Therefore, set up your tent in the shade when possible and use the rain fly to protect the inner tent
- To prolong the life of your tent floor, we recommend the use of a tent footprint or separate sheet of PE (tarpaulin) fabric underneath the tent floor to protect against abrasion
- When packing up, shake out dirt and sand as much as possible
- At home, clean your tent with a damp cloth, never use harsh cleaning chemicals, and air dry
- When storing, allow the tent to sit loosely to prevent creases