

Congratulations and thanks for your purchase!

We have tried to make the assembly instructions as clear and concise as possible so you can get on with enjoying your tent quickly and with minimal fuss.

We've also included some tips on how to prolong the life of your tent – if you follow this advice, you will be able to enjoy your tent for years to come!

Contents:

- 1 rain fly
- 3 inner tent
- 1 ground sheet
- 3 fiberglass poles
- 43 tent stakes
- 12 guy ropes
- 1 repair kit

Fury: Tent Assembly Instructions

1. Remove contents of the tent bag
2. Carefully assemble tent poles – do not let the shock cords snap the poles together
3. Unfold the inner tent and the rain fly
4. Insert each color coded tent pole into the corresponding color coded pole sleeve
5. Clip the tent poles to the rain fly using the pole clips
6. Insert the pins found at the bottom corners of the rain fly into both ends of each pole
7. Stake down the rain fly through the rings and webbing loops
8. Take the inner tents into the rain fly, clip the inner tent to the inside of the rain fly using the plastic rings and toggles starting from the bottom rear and working your way to the middle of the tent and towards the top – repeat for the remaining inner tents
9. Stake down the inner tent through the webbing straps
10. Tie the guy ropes to the tabs on the outside of the rain fly – adjust the tension of the guy ropes by sliding the black adjusters along the guy ropes

Caring for your tent:

1. Keep it clean: Don't set up your tent in the mud, avoid putting muddy clothing and gear in the sleeping compartments as sand and dirt can scratch the water proof coating and damage zippers
2. UV light can accelerate fabric degradation. Therefore, set up your tent in the shade when possible and use the rain fly to protect the inner tent
3. To prolong the life of your tent floor, use a separate sheet of PE fabric underneath the tent to protect against abrasion
4. When packing up, shake out dirt and sand as much as possible
5. At home, clean your tent with a damp cloth, never use harsh cleaning chemicals, and air dry
6. When storing, allow the tent to sit loosely to prevent creases