

Congratulations and thanks for your purchase!

We have tried to make the assembly instructions as clear and concise as possible so you can get on with enjoying your tent quickly and with minimal fuss.

We've also included some tips on how to prolong the life of your tent – if you follow this advice, you will be able to enjoy your tent for years to come!

**Contents:**

- 1 rain fly
- 3 inner tent
- 1 groundsheet
- 9 fiberglass poles
- 65 tent stakes
- 22 guy ropes
- 1 repair kit

**Tent Assembly Instructions, Model: MAELSTROM**

- Extend all the fiberglass poles on the ground. All poles are color coded to match the corresponding tent pole sleeve

**Rain Fly:**

- Lay the fly as flat as possible on the ground.
- Insert each color coded tent pole into the corresponding color coded pole sleeve
- Ideally, this tent should be set up by 4 people. Otherwise, a minimum of 2 people will be required to set up the fly.
- Start from the right side of the fly, fit the ends of the poles to all steel the "pin & ring" systems located at the bottom of the fly. Loosen the PP webbings if necessary.
- These 2 people then move to the two left sides of the main cabin separately, grab the ends of the 3 poles carefully and with a slight push/bending of the poles, the ends of the pole will fit into the steel "pin & ring" systems.
- Insert the remaining 3 poles (part 2) to the sleeves at the far ends of the 3 bedrooms, according to the matching colored hems. Make sure the ends of the poles fit into the steel "pin & ring" systems before bending the poles.
- Tension of the fly can be adjusted by tightening the PP webbings at the bottom of the fly.
- Anchor down all the corners of the fly with steel stakes.
- Same with the guys ropes that are tied to the fly.

**Inner tents:**

- The three inner tents can hung with pins at the roof and rings at the ceiling of the fly.
- Steel door poles: Entrance can be kept opened by the door poles and guy ropes.

**Caring for your tent:**

1. Keep it clean: Don't set up your tent in the mud, avoid putting muddy clothing and gear in the sleeping compartments as sand and dirt can scratch the water proof coating and damage zippers
2. UV light can accelerate fabric degradation. Therefore, set up your tent in the shade when possible and use the rain fly to protect the inner tent
3. To prolong the life of your tent floor, use a separate sheet of PE fabric underneath the tent to protect against abrasion
4. When packing up, shake out dirt and sand as much as possible
5. At home, clean your tent with a damp cloth, never use harsh cleaning chemicals, and air dry
6. When storing, allow the tent to sit loosely to prevent creases

Visit us online at [www.campingequipmentco.com](http://www.campingequipmentco.com) and be sure to join our Facebook and Twitter pages for new product information and to receive special offers and discounts on our camping equipment.



www.campingequipmentco.com  
Tent Assembly Instructions  
MAELSTROM

Visit us online at [www.campingequipmentco.com](http://www.campingequipmentco.com) and be sure to join our Facebook and Twitter pages for new product information and to receive special offers and discounts on our camping equipment.