

Congratulations and thanks for your purchase!

We have tried to make the assembly instructions as clear and concise as possible so you can get on with enjoying your SWAG quickly and with minimal fuss.

We've also included some tips on how to prolong the life of your SWAG – if you follow this advice, you will be able to enjoy your tent for years to come!

Contents:

- 1 swag
- fiberglass poles
- 6 tent stakes
- 2 guy ropes
- 1 repair kit

Assembly Instructions, Model: Wallaby

Poles and components:

- Extend all poles and line them up on the ground – each fiberglass pole is color coded to match the part of the tent that it belongs to

SWAG:

- Lay the SWAG on the ground as flat as possible
- Insert each fiberglass pole through each pole sleeves along the outside of SWAG
- Insert the ends of each pole into the pockets located at the bottom corners
- Stake down the SWAG through the PP webbing loops at the bottom corners to secure the SWAG
- Stake down the guy ropes which are attached to the tabs on the outside of the SWAG – this will keep it more stable in strong winds

Caring for your SWAG:

1. Keep it clean: Don't set up your tent in the mud, avoid putting muddy clothing and gear in the sleeping compartments as sand and dirt can scratch the water proof coating and damage zippers
2. UV light can accelerate fabric degradation. Therefore, set up your tent in the shade when possible and use the rain fly to protect the inner tent
3. To prolong the life of your tent floor, use a separate sheet of PE fabric underneath the tent to protect against abrasion
4. When packing up, shake out dirt and sand as much as possible
5. At home, clean your tent with a damp cloth, never use harsh cleaning chemicals, and air dry
6. When storing, allow the tent to sit loosely to prevent creases