

Congratulations and thanks for your purchase!

We have tried to make the assembly instructions as clear and concise as possible so you can get on with enjoying your tent quickly and with minimal fuss.

We've also included some tips on how to prolong the life of your tent – if you follow this advice, you will be able to enjoy your tent for years to come!

Tent Assembly Instructions: WASAGA

1. Poles and components: Remove all contents from tent bag
2. Extend all tent poles carefully
3. Unfold inner tent and rain fly and lay on ground

Rain Fly:

1. NOTE: All fiberglass poles are color coded to match the corresponding tent sleeves on the rain fly
2. Insert each fiberglass tent pole into the corresponding tent sleeve
3. Attach 1 black plastic elbow to the end of each fiberglass tent pole
4. Insert the narrow end of each steel pole into the opposite open end of each black plastic elbow
5. Insert metal pin (located along bottom edge of rain fly) into the ends of each steel tent pole
6. Fasten the steel poles to the rain fly using clips located along the edges of the rain fly
7. Stake down the rain fly through the tent stake loops (located along the bottom edge of the rain fly)
8. Tie the guy ropes to the guy rope tabs along the edges of the rain fly and stake to the ground – this will provide more stability against strong wind
9. The rain fly should now stand freely on the ground

Inner tents:

- Each inner tent hooks to the inside of the rain fly using a system of toggles and rings – certain toggles are color coded to aid in assembly
- Take the inner tent inside the assembled rain fly to its appropriate location
- Starting from the rear of the inner tent, stake down the corners along the bottom edge of the rain fly
- Hook the inner tent to the underside of the rain fly starting from the bottom rear and work your way forward to the top using the toggles on the outer wall of the inner tent and the corresponding rings running along the underside of the rain fly

Caring for your tent:

1. Keep it clean: Don't set up your tent in the mud, avoid putting muddy clothing and gear in the sleeping compartments as sand and dirt can scratch the water proof coating and damage zippers
2. UV light can accelerate fabric degradation. Therefore, set up your tent in the shade when possible and use the rain fly to protect the inner tent
3. To prolong the life of your tent floor, use a separate sheet of PE fabric underneath the tent to protect against abrasion
4. When packing up, shake out dirt and sand as much as possible
5. At home, clean your tent with a damp cloth, never use harsh cleaning chemicals, and air dry
6. When storing, allow the tent to sit loosely to prevent creases