



CAMPING EQUIPMENTCO.COM

www.campingequipmentco.com

Tent Assembly Instructions


MIGA

Congratulations and thanks for your purchase! This booklet will tell you everything you need to properly assemble your tent and maintain it.

Follow these instructions carefully and you'll enjoy many years of use – please note that this product is intended for mild, 3 season, family camping use and not for extreme conditions of weather and use

Practice setting-up and taking-down the tent a few times at home before use at the camping site.

1




Carrying bag X 1 Fly X 1 Repair kit X1

Guy rope X 2 Long PP Webbing X2 Plastic anchor X10

9.03 meters X 1 lines, 1 sections per line (already put in tent)


2



Remove the PP webbing and drop the folded tent gently to the ground.

The tent will stand on its own and now ready to be used.


3



Tie the pp webbing at two ends as shown in the sketch.



Stake down the tent corners.

4



Stake down the pp webbings.

Visit us online at www.campingequipmentco.com and be sure to join our Facebook and Twitter pages for new product information and to receive special offers and discounts on our camping equipment.



CARING FOR YOUR TENT:

- Keep it clean: Don't set up your tent in the mud, avoid putting muddy clothing and gear in the sleeping compartments as sand and dirt can scratch the water proof coating and damage zippers
- UV light can accelerate fabric degradation. Therefore, set up your tent in the shade when possible and use the rain fly to protect the inner tent
- To prolong the life of your tent floor, we recommend the use of a tent footprint or separate sheet of PE (tarpaulin) fabric underneath the tent floor to protect against abrasion
- When packing up, shake out dirt and sand as much as possible
- At home, clean your tent with a damp cloth, never use harsh cleaning chemicals, and air dry
- When storing, allow the tent to sit loosely to prevent creases